




Couzzi[®]
accessories

50.3017

50.3012


70 cm

20 cm



50.3013

50.3018



20 cm



70 cm



- 701
- 707
- 715
- 716
- 717
- 720
- 721
- 722
- 723

50.3027

50.3022

70 cm

20 cm



771



772



773



774



775



776



777



778



779



780



781



782



783

50.3032

50.3037

20 cm

70 cm



- 701
- 707
- 715
- 716
- 717
- 720
- 721
- 722
- 723

50.3047

50.3042

70 cm

20 cm



701



707



715



716



717



720



721



722



723



771



772



773



774



775



776



777



778



779



780



781



782



783



Guzzi[®]
accessories

50.3017.11

50.3012.11

9 cm

20 cm

70 cm



771



772



773



774



775



776



777



778



779



780



781



782



783

50.4047.31

50.4027.31



15 cm



11.4018



70 cm



701 707 715 716 717 720 721 722 723

50.3017.12

50.3012.12

9 cm

20 cm

70 cm



771



772



773



774



775



776



777



778



779



780



781



782



783

50.4037.32



15 cm

70 cm



11.4028



701



707



715



716



717



720



721



722



723

50.3017.13

50.3012.13

9 cm

20 cm

70 cm



771



772



773



774



775



776



777



778



779



780



781



782



783

50.4047.33



17,5 cm



11.4038



70 cm



701



707



715



716



717



720



721



722



723

50.3017.14

50.3012.14

9 cm

20 cm

70 cm



771



772



773



774



775



776



777



778



779



780



781



782



783

50.4047.34

50.4037.34



15 cm

70 cm



11.4048



701



707



715



716



717



720



721



722



723

50.3017.15

50.3012.15



50.4037.35



- 701
- 707
- 715
- 716
- 717
- 720
- 721
- 722
- 723

50.3017.16

50.3012.16

9 cm

20 cm

70 cm



771



772



773



774



775



776



777



778



779



780



781



782



783

50.4047.36



15 cm



11.4068



70 cm



701 707 715 716 717 720 721 722 723

50.3117.19

50.3112.19

7 cm

20 cm

70 cm



771



772



773



774



775



776



777



778



779



780



781



782



783

50.4127.19

50.4137.19



7 cm

70 cm



301



302



101



105



107



108

50.3117.20

50.3112.20

7 cm

20 cm

70 cm



771



772



773



774



775



776



777



778



779



780



781



782



783

50.4127.41

50.4137.42



301



302



101



105



107



108

50.3117

50.3112

70 cm

20 cm



771



772



773



774



775



776



777



778



779



780



781



782



783

50.3113

50.3118

20 cm

70 cm



101



105



107



108

50.3127

50.3122



771



772



773



774



775



776



777



778



779



780



781



782



783

50.3132

50.3137



20 cm



70 cm



101



105



107



108

50.4137.37

50.3117.17

50.3112.17

20 cm

10 cm

20 cm

70 cm



771



772



773



774



775



776



777



778



779



780



781



782



783

50.3112.18

50.3117.18

50.4137.38

10 cm

20 cm

20 cm

70 cm

70 cm



101



105



107



108

50.4127.39

50.4137.40

20 cm

70 cm



101



105



107



108



771



772



773



774



775



776



777



778



779



780



781



782



783



Couzzi[®]
accessories

50.3117.21

50.3112.21

7 cm

70 cm



16.2267



16.2268



771



772



773



774



775



776



777



778



779



780



781



782



783

50.4127.21

50.4127.47

50.4127.48

50.4127.49



7 cm

9 cm

70 cm



101



105



107



108

50.4137.43

50.4137.44

50.4137.45

50.4137.46

70 cm

7 cm
9 cm



771



772



773



774



775



776



777



778



779



780



781



782



783

50.4137.51

50.4127.50



2,8 cm
3,6 cm
4,5 cm

3,5 cm
4,2 cm
5 cm



70 cm



101



105



107



108

50.4127.52

5 cm

7 cm

9 cm

70 cm



101



105



107



108



771



772



773



774



775



776



777



778



779



780




781



782



783





Couzzi[®]
accessories

PÜSKÜL ve KORDON RENKLERİ / TASSEL and CORDON COLORS





701



707



715



716



717



720



721



722



723


METAL RENKLERİ / METAL COLORS




101



105



107



108